



CEQUENCE

CEQUENCE SLATTED PANELS ATTACHING TO A EXISTING BRICK OR BLOCK WALL



INSTALLATION MANUAL

CEQUENCE




1

Typical existing wall run

2


Attach horizontal timber battens in three rows, top middle and bottom to the existing wall. These battens can be fixed into place by screwing into the wall face with a plug and screw.



New horizontal timber battens screwed to existing wall


3

Screw new cedar vertical boards to the horizontal battens. The position of these cedar boards should be so that new panels sit to the centre of each board and to the outer edge at the end of the runs.



New vertical cedar boards screwed to horizontal battens

CEQUENCE



4


New Cequence fence panels are to be screwed onto the vertical cedar boards.

Screws should pass through the gaps between the horizontal battens into the front of the back batten and then into the vertical cedar board.

5

Align the next panel ensuring the batten positions match and line up. Use a Spirit Level to make sure the top line is level.


The panel should be flush with the outer edge of the vertical cedar board at the start and end of a run



6

The Capping Rail is pushed down onto the cedar vertical board top and back batten upstand.

3off 63mm cedar coloured powder coated stainless steel screws should be used to fix the capping rail into position.



CEQUENCE



7

Completed fence run